

Quick Start Guide

Elinx Gigabit Ethernet Switch EIR408-T



1

Items Included

- Ethernet Switch
- CD with Support Manual
- This Quick Start Guide
- Panel Mount Bracket

2

Hardware Installation

1. Select a mounting location and install the switch onto a piece of DIN rail or use the included panel mount brackets for wall or panel mounting
2. Connect power to the switch
 - 12 to 48 VDC
 - If redundancy is desired be sure to connect two separate power supplies by using the two DC inputs on the terminal blocks
 - If only one power input is used the Fault LED will light (this is normal)



3


LED Chart

LED	Description	
P1	Green	Power input 1 is active
	Off	Power input 1 is inactive
P2	Green	Power input 2 is active
	Off	Power input 2 is inactive
Fault	Red	Power input 1 or 2 is inactive
	Off	Power inputs 1 and 2 are both active, or no power is present
Copper Port (Upper LED)	Green	Connected to network
	Flashing	Networking is active
	Off	Not connected to network
Copper Port (Lower LED)	Green	Connected to network at 1000Mbps
	Off	Not connected to 1000Mbps network

4

Ports

RJ-45 ports: The RJ-45 ports auto-sense for 10, 100 or 1000 Mbps devices connections. The auto MDI/MDIX feature allows connections to switches, workstation and other equipment without changing straight through or crossover cabling. The charts below show the cable pin assignments for straight through and crossover cables.



1. Auto MDI/MDI-x is supported. A straight through or cross-over cable may be used.

2. 10/100/1000 auto negotiation and full/half-duplex are supported.

MDI Cable Pinout

Pin	Signal
1	Tx+
2	Tx-
3	Rx+
6	Rx-

MDI-X Cable Pinout

Pin	Signal
1	Rx+
2	Rx-
3	Tx+
6	Tx-

5

Installation Complete

1. When the network cables are attached and power is applied, installation is complete.
2. The switch will automatically discover network devices, populate its MAC address table, and pass traffic to the appropriate ports.